



AROMA NEBULIZER WITH LAMP


榉木陶瓷冷香仪



开始使用冷香仪


在正式开始使用产品前，我们建议您先完整阅读本手册，以保证更好的产品使用体验。请保管好本手册，以便后续再次查询。

产品描述




操作前准备


1. 取下陶瓷上盖。




2. 取下精油杯盖子。




3. 滴入10至20滴精油（单方或复方均可）。




4. 盖回精油杯盖子。




5. 盖回陶瓷上盖。



6. 在产品背后插上电源插头。



将适配器插到插座上。



技术规格

工作时间：每次开机工作2小时 - 以1分钟开/2分钟关方式循环。

输入：100-240V - 50Hz

输出：15V / 0.5A , 7.5W

扩散面积：20-25平方米


灯光：暖色LED灯

附件：说明书，适配器，手工玻璃精油杯




按钮功能说明

扩香：



顺时针旋转按钮：打开扩香功能，并增大雾量



逆时针旋转按钮：减小雾量，并关闭扩香功能

扩香功能每次开启后，持续工作2个小时后自动关闭。工作时以1分钟开/2分钟关方式循环。

LED氛围灯

1. 第一次按压开关灯光全开。
2. 第二次按压开关灯光半开。
3. 第三次按压开关开始呼吸灯功能。
4. 第四次按压开关关闭灯光功能。



冷香仪保养

日常清理：

请至少每周清理玻璃精油杯一次。经常清理精油杯有助于保证良好的扩香效果。




1. 取下精油杯盖子。
2. 在精油杯内倒入几滴厨房清洗液和少量清水。
3. 开启冷香仪10分钟。
4. 用清水冲洗精油杯。

完整保养：

建议每月对产品做一次完整保养。


1. 在一个容器内加入热水和适量厨房清洗液后，放入精油杯浸泡。
2. 将精油杯没顶浸泡1小时，然后取出用清水冲洗。放在干燥处晾干后，可进行下次使用。



使用须知

- 在滴精油时，请注意勿将精油留在木底座表面，以避免损害木器表面。
- 请勿在尘土较多处使用扩香仪，以避免灰尘堵住玻璃精油杯内吸管。
- 为了保证您的健康，请确认使用纯天然精油。
- 扩香效果会因为精油浓稠程度与香气特质有相应区别。
- 请勿添加过量精油。


⚠ 请始终保证液面在玻璃精油杯内2个细管顶端以下。



Introduction


Congratulations on your purchase!
Before using this product, please read this manual and keep it.

Product Description




Instructions for use


1. Remove the top cover.




2. Remove the glass cover.




3. Add 10 to 20 drops of essential oil (or pure essential oil blend).




4. Close the glass cover.




5. Put back the top cover.



6. Plug the DC socket behind the diffuser.



Plug the adaptor to the wall socket.



Technical data

Function duration: 2 hours - 1 min<ON> / 2 min<OFF>

Power adapter(Input): 100-240V - 50 Hz

Power adapter(Output): 15V / 0.5A

Output power: 7.5W

Diffusing space: 20-25 m²


LED Light: Warm lighting

Accessories: Instruction Manual + Adaptor + Glass Oil Tanks




Function explanation

Diffusion:



Switch **ON** and adapt mist level
turn the button clockwards



Switch **OFF** and adapt mist level
turn the button anti clockwards

Remark: The diffusion cycle is 1 min ON and 2 min OFF. It will stop automatically after 2hours. To start again, switch ON again.

LED light:

1st click
Brighter light

2nd click
Weaker light



3rd click
Breathing light

4th click
Turn off light

Clean aroma diffuser

Regular clean-up:

Cleaning the diffuser reservoir: you should clean the diffuser reservoir once a week if you use it 2 hours a day. This will help the diffuser last longer.




1. Remove the glass cap.
2. Pour some alcohol in the glass reservoir. Do not overfill.
3. Switch on the nebuliser for 5 to 10 min.

Full clean up:

You can fully clean the diffuser reservoir once a month in order to maintain optimum product quality.

1. Prepare a container filled with hot water and gentle detergent and put the glass reservoir in the hot water.

2. Keep the glass reservoir and glass cap in the water for one hour. Then take out the reservoir and cap and rinse well with water. Let dry before using again.



Trouble shooting page

Protect your diffuser

- Do not allow essential oil to run down the outside of the reservoir when filling, as it might harm the wood base.
- When running, keep your diffuser in a relatively dust-free location to prevent the blocking of the micro tubes.

Essential oils

- The unit works well with most pure essential oils, except for the very thickest. Please make sure you are using pure essential oils.
- Never overfill to avoid blocking the micro tubes.

- ⚠ Keep the oil level below the top of the two small glass tubes at the bottom of the glass oil tank.

